

NO DRILL INSTALLATION

NORTH AMERICAN MADE QUALITY

THE BRAND NAME YOU TRUST

BACKRACK

- No drill installation on most trucks
- Fastens using Backrack's exclusive no drill hardware
- North American made, including the steel.
- Competitors products made offshore and require drilling
- Industry leading Powder Coat Finish
- Quality that competitors simply can't match
- Cool, sleek looks that compliment your truck.
- Customize with bolt on accessories.



SAFETYRACK

- No drill installation on most trucks
- Fastens using Backrack's exclusive no drill hardware
- All the quality features of the Backrack (see left)
- Screen fully welded at each intersection
- Heavy Duty 3/16" Cold Rolled wire screen
- Full cab protection provides safety and security



SIDERAILS

- No drill installation
- Industrial Grade Quality & Strength
- Designed for working pickup trucks
- Compatible with or without Toolboxes
- Compatible with or without Backrack & Safetyrack
- Available for 6.5 & 8 ft beds

NEW PRODUCT

See index for Siderail in this catalogue



YEAR/MAKE & MODEL	BACKRACK	BACKRACK (With Toolbox)	SAFETYRACK	SAFETYRACK (With Toolbox)	REAR BAR	TOOLBOX BRACKET <small>If sold separately. No hardware.</small>
CHEV/GMC						
2007-08 Silverado, Sierra (New Body)	10519	10519 TB	10500 + 30119	10500 + 30119 TB	11519	91010
1999-07 Silverado, Sierra, Classic	10509	10509 TB	10400 + 30109	10400 + 30109 TB	11509	91010
1988-98 Fullsize CK Series	10503	10503 TB	10400 + 30103	10400 + 30103 TB	11503	91010
1968-87 Fullsize, Chev, GMC	10504	10504 TB	10400 + 30103	10400 + 30103 TB	11504 C	91010
2004-08 Colorado, Canyon	10316	10316 TB **	10200 + 30116	10200 + 30116 TB		91010-C
1985-2005, S10, S15 Compact	10312	10312 TB **	10200 + 30113	10200 + 30113 TB		91010-C
DODGE						
2002-08 Dodge Ram, Fullsize	10517	10517 TB	10400 + 30117	10400 + 30117 TB	11517	91010
1994-01 Dodge Ram, Fullsize	10507	10507 TB	10400 + 30107	10400 + 30107 TB	11507	91010
1963-93 Dodge Ram, Fullsize	10504	10504 TB	10400 + 30103	10400 + 30103 TB		91010
2005-08 Dakota	10314	10314 TB **	10200 + 30113	10200 + 30113 TB		91010-C
1987-04 Dakota	10313	10313 TB **	10200 + 30113	10200 + 30113 TB		91010-C
FORD						
1999-08 Superduty, F250, 350, 450	10501	10501 TB	10300 + 30201	10300 + 30201 TB	11501	91011
2004-08 F150, 6.5 ft & 8 ft Beds	10512	10512 TB	10500 + 30112	10500 + 30112 TB	11512	91013
2004-08 F150, 5.5 ft Bed (Supercrew)	10512 SC	10512 SCTB	10500 + 30104	10500 + 30104 TB		91010-C
1997-03 F150, F250, 6.5 ft & 8 ft beds.	10502	10502 TB	10400 + 30102	10400 + 30102 TB	11502	91012
1997-03 F150, 5.5 ft Bed (Supercrew)	10502 SC	10502 SCTB	10400 + 30104	10400 + 30104 TB		91010-C
1975-96 F150, F250, 8 ft Bed	10506	10506 TB	10400 + 30106	10400 + 30106 TB	11506	91010
1975-96 F150, F250, 6.5 ft Bed	10505	10506 TB	10400 + 30105	10400 + 30106 TB	11506	91010
1993-08 Ranger	10311	10311 TB **	10200 + 30111	10200 + 30111 TB	11310 R	91010
TOYOTA						
2008 Fullsize Tundra	10518	10518 TB	10500 + 30118	10500 + 30118 TB	11518	91010
2005-08 Tacoma	10317 **	N/A	10200 + 30317			
1995-07 Tundra	10508	10508 TB	10400 + 30108	10400 + 30108 TB	11508	91010
1993-98 T-100	10508	10508 TB	10400 + 30108	10400 + 30108 TB		91010
1995-07 Tacoma	10313	10313 TB **	10200 + 30113	10200 + 30113 TB		91010-C
MAZDA						
1993-08 B-Series	10311	10311 TB **	10200 + 30111	10200 + 30111 TB	11310 R	91010
NISSAN						
2004-08 Titan, Fullsize	10511	10511 TB	10400 + 30511	10400 + 30511 TB		91010
2005-08 Frontier	10314	10314 TB **	10200 + 30113	10200 + 30113 TB		91010-C
1987-04 Compact	10312	10312 TB **	10200 + 30113	10200 + 30113 TB		91010-C

**Frame & Hardware Kit Shipped Separate

ACCESSORIES

Backrack's are accessory friendly. Our customers use their trucks for work so we provide a full range of accessories that simply bolt on allowing you to mount strobes, beacons, toolboxes and most any accessory without drilling one hole in your truck. Our website has a full listing. www.backrack.com.

TOOLBOX BRACKETS

Toolbox Brackets are included with your Backrack or Safety Rack Hardware Kit if you specify "TB" after part # ie (10519 TB or 30119 TB). They are sold separately also but do not include mounting hardware. Sold separate applications are below:

- **91010** - fits 105(03),04,05,06,07,08,09,11,17,18,19,10311
- **91011** - fits 10501 only
- **91012** - fits 10502 only
- **91013** - fits 10512 only
- **91010-C** - fits 103(12),13,14,16,502SC, 512SC

Note: 31" Brackets also available add "-31" to part# (91010-31)



REAR BARS

Turn your Backrack or Safety Rack into a ladder rack with our REAR BAR accessory. Simply drops snug into rear stakepockets. Removes quickly when not needed. Maintains your trucks good looks while providing you with a functional ladder rack.

**See application chart (left) to select the right one for your truck.



LIGHT BRACKETS



81001 Driver Side
81003 Passenger Side
6-1/2" Octagon Base



91001 Driver Side
91002 Center
91003 Passenger Side
10-1/2" Octagon Base



91001F Driver Side
91002REC Center Rec.
91003F Passenger Side
Park Underground



91004 Adapts to most arrow sticks. Comes with 4 self tap screws. Can also be used with Safety Rack



91002REC Center
91007 D & P Side Mount
16" x 7" Rectangle Base



91006 2"L" Brackets (pr) L Brkts. Adapts to most Light Bars



91005 (pr) L Brkts
7/16" hole for stud mount



91008 Mounts most antennas 3.5" x 3.5" mount surface with 7/8" pre-drilled hole
No drilling required



41000 Built to mount on Safety Rack. 10.5" x 10.5" mount surface. Self tap screws included. Two can be paired to mount a variety of accessories and lights.